

VJ-2000M VIDEO BREAKER

A. Specification

01	TX frequency 895/900 ~ 1000 MHz
02	TX frequency 1195 /1200 ~ 1300MHz
03	TX frequency 2395/2400 ~ 2500 MHz
04	Total output power : > 3.9W (900:1.3W, 1200:1.3W , 2400:1.3 W ,)
05	TNC antenna connector.
06	Automatic power switching power supply : 50/60Hz/AC 100 ~ 240V transmitting to DC 12V
07	Dimension : 238mm(L)×186mm(W)×53mm(H)
08	Weight : 2 Kg
09	Operating temperature:-10°C ~ +60°C
10	Humidity: 5% ~ 80%
11	Jamming range : Radius > 20 ~ 30 M 【the signal must
12	Safety Regulation: AC Adapter UL (E190582), CSA (LR112971 Level 3)

B. Installation

01. Take the Breaker out of the packing box.
02. Plug in the antenna according to the frequencies.
03. Plug in the AC power and then plug in DC jack to the Jammer.
04. When the LED is on, the Jammer is activated.

C. Important Notice

01. Before turn on the power, please make sure both antennas are correctly plug in.
02. The antennas have to plug in according to the frequency to the right connector to prevent short circuit.

